


A. Description of Front Panel.



1. The Status Array of LEDs

(Light Emitting Diodes) indicate at a glance the status of alertness of the security guard during the night .

Red Indicates Absent or Not alert

Green Indicates Present or Alert

The time at which the status led indicates is printed near the LED's.

2. Today's STATUS

This Switch has to be pressed to Indicate the Status of alertness of the Night just elapsed.

As soon as it is pressed The LED Array display comes on and Indicates the Status.

2. DAY OLD STATUS

This Switch has to be pressed to Indicate the Status of alertness of 9 Days earlier to the Night just elapsed. Hence any day's Status Remains in memory for 9 days and is replaced on "first in first out" FIFO basis.

As soon as the switch is pressed the Day displays just above the switch indicates "0" meaning the status of LED array is that of the Night just elapsed.

Now pressing the switch again indicates "1" on the DAY display Meaning that the status is of the previous Night.

DAY	Status LED Array is of	Example if Day old Status is pressed on 14th morning.
0	The Night just passed.	PM is 13th & AM is 14th
1	Previous Night	PM is 12th & AM is 13th
2	Night before Two nights passed	PM is 11th & AM is 12th
3	Night before Three nights passed	PM is 10th & AM is 11th
4	Night before Four nights passed	PM is 09th & AM is 10th
5	Night before Five nights passed	PM is 08th & AM is 09th
6	Night before Six nights passed	PM is 07th & AM is 08th
7	Night before Seven nights passed	PM is 06th & AM is 07th
8	Night before Eight nights passed	PM is 05th & AM is 06th
9	Night before Nine nights passed	PM is 04th & AM is 05th

Operating Date minus "DAY INDICATION" is the date of the AM part of STATUS Array LEDs.

3. POWER

This LED Lamp is on when Mains Power is available and mains chord is connected properly. This Lamp goes off on Mains Power Shutdown.



If POWER Lamp is off it means the Unit is running on battery Check if Mains Plug is connected to the 3 PIN socket Properly.

The Unit has Battery BACKUP for 48 hrs Maximum And mains supply is required to charge Battery.

4. **CLOCK**

This LED is always flashing to Indicate the unit is working. and real time clock is active.

5. **SWITCH STUCK**

This LED is Always On if the Switch on the TERMINAL unit is STUCK Artificially indicating the security guard is misusing the unit.

6. **BATTERY LOW**

If this comes on it means mains supply has been absent for a long time and battery has to be charged immediately.



If Battery LOW is Continuously on Contact the Service person at once.

7. **BACK PANEL MAINS SWITCH and FUSE**

These will be Operated only Service Person and Should not be Tampered with.