



T1  
Transformer  
Pri 40 turns 36 swg  
Sec 90 turns 36 swg  
wind pri first  
Insulation tape between pri and sec  
wind sec next  
cover final sec with tape  
Pot core HK100 OL  
18mm dia 10mm ht  
Use a pot core clamp  
or nylon nut bolt  
to fix to pcb

**delabs Technologies**  
Electronic Product and Process Design  
san@delabs.net  
ananth@dapj.net  
delabs.net  
dapj.com

Size B	Document Number DACT0020.SCH	Rev 00
Date: Monday, August 11, 2003	Sheet 1 of 1	